

Things You'll Need

- Scissors
- Something to clean the surface with
- Masking Tape
- Squeegee (An old credit card works great)

- 1.** Thoroughly clean the surface you are applying the decal to. Be sure all grease and oils are removed. Do not use an ammonia based cleaner!
- 2.** Unroll the decal and squeegee to flatten out.
- 3.** Position the decal on the wall where you want it, labeled side against the wall(you should be able to see the decal through the opaque transfer tape). Tape the top corners in place, then tape across the middle of the decal (horizontally for long vertical decals, and vertically for long horizontal decals).
- 4.** Starting at the bottom peel the opaque transfer tape from the shiny backing paper. Work SLOWLY making sure the vinyl decal sticks to the opaque transfer tape. When you have peeled all the way to the middle where you taped stop and cut the shiny backing paper off.
- 5.** Starting from the middle, working towards the edges and downward, squeegee the opaque transfer tape with the vinyl to the wall being careful not to crease or trap air bubbles.
- 6.** Remove the masking tape from the middle and top corners allowing the top of the decal to fall forward away from the wall. Peel the opaque transfer tape from the shiny backing paper like before.
- 7.** Squeegee the opaque transfer tape and vinyl to the wall working from the center towards the edges and up being careful not to crease or trap air bubbles.
- 8.** Squeegee the entire decal to the wall using some force. Try to work any air bubbles out from under the vinyl.
- 9.** Remove the opaque transfer tape from the wall slowly making sure the vinyl stays adhered to the wall. If the Vinyl lifts from the wall gently squeegee it back onto the wall and continue.
- 10.** If any air bubbles remain take a pin and gently pop the bubble and squeegee down.